



# D-CHAIR

## User manual






Seat height adjustment




Backrest travel with backrest lock in upright position



Tilt tension adjustment






2D, 4D adjustable  
armrests

Height adjustment at armrest carrier


105 mm  
run range



2D, 4D  
adjustable  
armrests

Pad adjustment forward and backwards

50 mm run  
range




4D adjustable  
armrests

Pad adjustment sideways


25 mm  
run range




2D (two directions) adjustable armrests  
4D (four directions) adjustable armrests



4D adjustable  
armrests



Pad rotation adjustment 15° one direction



Self-brake castors



for soft floor



for hard floor

Note. Self-braking chair castors initiate the integrated friction break and stop moving when the chair is unused (no weight is applied to the seat).

4D (four directions) adjustable armrests

## Other documents available for this product

Technical information for D-CHAIR chair family